


## HIGH-QUALITY MOTOR



**MODELO:- BON-P-GE-7.0HP**



<b>Numero de pieza</b>	<b>BOHNOEFFER CODIGO</b>	<b>DESCRIPCION EN ESPANOL</b>	<b>DESCRIPTION IN ENGLISH</b>
1	BON-P-GE-7.0HP-1	Perno, M6 x 16	Bolt, M6x16
2	BON-P-GE-7.0HP-2	Tapa de la válvula	Valve Cover
3	BON-P-GE-7.0HP-3	Manguera de respiradero	Breather Hose
4	BON-P-GE-7.0HP-4	Junta, tapa de válvula	Gasket, Valve Cover
5	BON-P-GE-7.0HP-5	Conjunto de balancines	Rocker Arm Assembly
6	BON-P-GE-7.0HP-6	Base del balancín	Rocker Arm Base
7	BON-P-GE-7.0HP-7	Perno, M6 x 10	Bolt, M6x10
8	BON-P-GE-7.0HP-8	Sudario	Shroud
9	BON-P-GE-7.0HP-9	Tapa de ajuste de válvula, escape	Valve Adjust Cap, Exhaust
10	BON-P-GE-7.0HP-10	Asiento de resorte de válvula	Valve Spring Seat
11	BON-P-GE-7.0HP-11	Asiento de resorte de válvula	Valve Spring Seat
12	BON-P-GE-7.0HP-12	Resorte de válvula	Valve Spring
13	BON-P-GE-7.0HP-13	Sello de la válvula de admisión	Intake Valve Seal
14	BON-P-GE-7.0HP-14	Perno, M8 x 65	Bolt, M8x65

15	BON-P-GE-7.0HP-15	Cabeza de cilindro	Cylinder Head
16	BON-P-GE-7.0HP-16	Tuerca, M8	Nut, M8
17	BON-P-GE-7.0HP-17	Silenciador	Muffler
18	BON-P-GE-7.0HP-18	Junta, silenciador	Gasket, Muffler
19	BON-P-GE-7.0HP-19	Espárrago, M8 × 34	Stud, M8×34
20	BON-P-GE-7.0HP-20	Bujía	Spark Plug
21	BON-P-GE-7.0HP-21	Espárrago, M6 × 110	Stud, M6×110
22	BON-P-GE-7.0HP-22	Junta, aislante del carburador	Gasket, Carburetor Insulator
23	BON-P-GE-7.0HP-23	Aislante	Insulator
24	BON-P-GE-7.0HP-24	Junta, carburador	Gasket, Carburetor
25	BON-P-GE-7.0HP-25	Carburador	Carburetor
26	BON-P-GE-7.0HP-26	Junta, carburador	Gasket, Carburetor
27	BON-P-GE-7.0HP-27	Conjunto de filtro de aire	Air Filter Assembly
28	BON-P-GE-7.0HP-28	Cubierta del filtro de aire	Air Filter Cover
29	BON-P-GE-7.0HP-29	Cubierta del filtro de aire	Air Filter Cover
30	BON-P-GE-7.0HP-30	Tuerca de mariposa	Butterfly Nut
31	BON-P-GE-7.0HP-31	Elemento de filtro de aire	Air Filter Element
32	BON-P-GE-7.0HP-32	Junta, filtro de aire	Gasket, Air Filter
33	BON-P-GE-7.0HP-33	Cubierta inferior del filtro de aire	Air Filter Lower Cover
34	BON-P-GE-7.0HP-34	Hoja del silenciador	Muffler Sheet
35	BON-P-GE-7.0HP-35	Conjunto de la base del filtro de aire	Air Filter Base Assembly
36	BON-P-GE-7.0HP-36	Tuerca, M6	Nut, M6
37	BON-P-GE-7.0HP-37	Culata Junta	Gasket, Cylinder Head
38	BON-P-GE-7.0HP-38	Pin, $\phi 10 \times 16$	Pin, $\phi 10 \times 16$
39	BON-P-GE-7.0HP-39	Varilla de empuje	Push Rod
40	BON-P-GE-7.0HP-40	Alzaválvulas	Tappet
41	BON-P-GE-7.0HP-41	Válvula de escape	Exhaust Valve
42	BON-P-GE-7.0HP-42	Válvula de admisión	Intake Valve
43	BON-P-GE-7.0HP-43	Juego de anillos de pistón	Piston Ring Set

44	BON-P-GE-7.0HP-44	Anillo de seguridad	Circlip
45	BON-P-GE-7.0HP-45	Pasador del pistón	Piston Pin
46	BON-P-GE-7.0HP-46	Pistón	Piston
47	BON-P-GE-7.0HP-47	Ensamblaje de biela	Connecting Rod Assembly
48	BON-P-GE-7.0HP-48	Perno, M8 × 32	Bolt, M8×32
49	BON-P-GE-7.0HP-49	Sello de aceite, $\phi 25 \times \phi 41.25 \times 6$	Oil Seal, $\phi 25 \times \phi 41.25 \times 6$
50	BON-P-GE-7.0HP-50	Tapón de aceite	Oil Plug
51	BON-P-GE-7.0HP-51	Junta tórica, $\phi 15,8 \times 2,5$	O-Ring, $\phi 15.8 \times 2.5$
52	BON-P-GE-7.0HP-52	Tapa del cárter	Crankcase Cover
53	BON-P-GE-7.0HP-53	Junta, cárter	Gasket, Crankcase
54	BON-P-GE-7.0HP-54	Pin, $\phi 8 \times 14$	Pin, $\phi 8 \times 14$
55	BON-P-GE-7.0HP-55	Cojinete, 6205	Bearing, 6205
56	BON-P-GE-7.0HP-56	Árbol de levas	Camshaft
57	BON-P-GE-7.0HP-57	Cigüeñal	Crankshaft
58	BON-P-GE-7.0HP-58	Llave Woodruff	Woodruff Key
59	BON-P-GE-7.0HP-59	Sensor de aceite	Oil Sensor
60	BON-P-GE-7.0HP-60	Varilla graduada	Dipstick
61	BON-P-GE-7.0HP-61	Gobernador Gear	Governor Gear
62	BON-P-GE-7.0HP-62	Conjunto de soporte de engranaje del gobernador	Governor Gear Bracket Assembly
63	BON-P-GE-7.0HP-63	Perno, M6 × 12	Bolt, M6×12
64	BON-P-GE-7.0HP-64	Perno, M6 × 28	Bolt, M6×28
65	BON-P-GE-7.0HP-65	Abrazadera	Clamp
66	BON-P-GE-7.0HP-66	Manguera de combustible	Fuel Hose
67	BON-P-GE-7.0HP-67	Chaqueta de la manguera de combustible	Fuel Hose Jacket
68	BON-P-GE-7.0HP-68	Palanca del gobernador	Governor Lever
69	BON-P-GE-7.0HP-69	Pasador de chaveta	Cotter Pin
70	BON-P-GE-7.0HP-70	Sello de aceite, $\phi 6 \times \phi 11 \times 4$	Oil Seal, $\phi 6 \times \phi 11 \times 4$
71	BON-P-GE-7.0HP-71	Junta tórica, $\phi 5.2 \times 1.9$	O-Ring, $\phi 5.2 \times 1.9$

72	BON-P-GE-7.0HP-72	Eje del engranaje del gobernador	Governor Gear Shaft
73	BON-P-GE-7.0HP-73	Tapa del combustible	Fuel Cap
74	BON-P-GE-7.0HP-74	Depósito de combustible	Fuel Tank
75	BON-P-GE-7.0HP-75	Tuerca, M6	Nut, M6
76	BON-P-GE-7.0HP-76	Primavera del gobernador	Governor Spring
77	BON-P-GE-7.0HP-77	Vínculo del acelerador	Throttle Linkage
78	BON-P-GE-7.0HP-78	Primavera inactiva	Idle Spring
79	BON-P-GE-7.0HP-79	Caja del cigüeñal	Crankcase
80	BON-P-GE-7.0HP-80	Perno de tierra	Earth Bolt
81	BON-P-GE-7.0HP-81	Arandela, $\phi 10 \times 1,5 \times \phi 16$	Washer, $\phi 10 \times 1.5 \times \phi 16$
82	BON-P-GE-7.0HP-82	Módulo de ignición	Ignition Module
83	BON-P-GE-7.0HP-83	Perno, M6 $\times$ 25	Bolt, M6 $\times$ 25
84	BON-P-GE-7.0HP-84	Escudo inferior	Lower Shield
85	BON-P-GE-7.0HP-85	Perno, M6 $\times$ 12	Bolt, M6 $\times$ 12
86	BON-P-GE-7.0HP-86	Sensor de aceite	Oil Sensor
87	BON-P-GE-7.0HP-87	Acortar	Clip
88	BON-P-GE-7.0HP-88	Perno, M6 $\times$ 20	Bolt, M6 $\times$ 20
89	BON-P-GE-7.0HP-89	Sello de aceite, $\phi 25 \times \phi 41.25 \times 6$	Oil Seal, $\phi 25 \times \phi 41.25 \times 6$
90	BON-P-GE-7.0HP-90	Volante	Flywheel
91	BON-P-GE-7.0HP-91	Ventilador	Cooling Fan
92	BON-P-GE-7.0HP-92	Copa de inicio	Starter Cup
93	BON-P-GE-7.0HP-93	Tuerca, M14 $\times$ 1,5	Nut, M14 $\times$ 1.5
94	BON-P-GE-7.0HP-94	Sudario	Shroud
95	BON-P-GE-7.0HP-95	Arrancador de retroceso	Recoil Starter
96	BON-P-GE-7.0HP-96	Perno, M6 $\times$ 14	Bolt, M6 $\times$ 14
97	BON-P-GE-7.0HP-97	Interruptor de parada	Stop Switch