


LISTA DE REPUESTOS: - Motor de Gasolina (16HP)



MODELO: BON-P-GE16 HP



S. NO	BOHNOEFFER CODIGO	DESCRIPCION EN ESPANOL	DESCRIPTION IN ENGLISH
1	BON-P-GE-16.0HP-1	Perno, M6 x 16	Bolt, M6x16
2	BON-P-GE-16.0HP-2	Tapa de la válvula	Valve Cover
3	BON-P-GE-16.0HP-3	Manguera de respiradero	Breather Hose
4	BON-P-GE-16.0HP-4	Junta, tapa de válvula	Gasket, Valve Cover
5	BON-P-GE-16.0HP-5	Conjunto de balancines	Rocker Arm Assembly
6	BON-P-GE-16.0HP-6	Base del balancín	Rocker Arm Base
7	BON-P-GE-16.0HP-7	Armario de válvulas	Valve Locker
8	BON-P-GE-16.0HP-8	Tapa de ajuste de válvula, escape	Valve Adjust Cap, Exhaust
9	BON-P-GE-16.0HP-9	Asiento de resorte de válvula	Valve Spring Seat
10	BON-P-GE-16.0HP-10	Resorte de válvula	Valve Spring
11	BON-P-GE-16.0HP-11	Sello de la válvula de admisión	Intake Valve Seal
12	BON-P-GE-16.0HP-12	Asiento de resorte de válvula	Valve Spring Seat
13	BON-P-GE-16.0HP-13	Perno, M10 x 1,25 x 87	Bolt, M10x1.25x87
14	BON-P-GE-16.0HP-14	Cabeza de cilindro	Cylinder Head
15	BON-P-GE-16.0HP-15	Bujía	Spark Plug
16	BON-P-GE-16.0HP-16	Espárrago, M8 x 47	Stud, M8x47

17	BON-P-GE-16.0HP-17	Junta, silenciador	Gasket, Muffler
18	BON-P-GE-16.0HP-18	Tubo de escape	Exhaust Pipe
19	BON-P-GE-16.0HP-19	Tuerca, M8	Nut, M8
20	BON-P-GE-16.0HP-20	Sudario	Shroud
21	BON-P-GE-16.0HP-21	Espárrago, M6-8 × 110	Stud, M6-8×110
22	BON-P-GE-16.0HP-22	Junta, carburador aislante	Gasket, Carburetor Insulator
23	BON-P-GE-16.0HP-23	Aislante	Insulator
24	BON-P-GE-16.0HP-24	Junta, carburador	Gasket, Carburetor
25	BON-P-GE-16.0HP-25	Carburador	Carburetor
26	BON-P-GE-16.0HP-26	Junta, filtro de aire	Gasket, Air Filter
27	BON-P-GE-16.0HP-27	Arrancador de retroceso	Recoil Starter
28	BON-P-GE-16.0HP-28	Arandela, φ6	Washer, φ6
29	BON-P-GE-16.0HP-29	Perno, M6 × 10	Bolt, M6×10
30	BON-P-GE-16.0HP-30	Soporte del filtro de aire	Air Filter Bracket
31	BON-P-GE-16.0HP-31	Sudario	Shroud
32	BON-P-GE-16.0HP-32	Perno, M5 × 10	Bolt, M5×10
33	BON-P-GE-16.0HP-33	Conjunto de filtro de aire	Air Filter Assembly
34	BON-P-GE-16.0HP-34	Clip de filtro de aire	Air Filter Clip
35	BON-P-GE-16.0HP-35	Base del filtro de aire	Air Filter Base
36	BON-P-GE-16.0HP-36	Junta, filtro de aire	Gasket, Air Filter
37	BON-P-GE-16.0HP-37	Deflector del filtro de aire	Air Filter Baffle
38	BON-P-GE-16.0HP-38	Elemento de filtro de aire	Air Filter Element
39	BON-P-GE-16.0HP-39	Cubierta del filtro de aire	Air Filter Cover
40	BON-P-GE-16.0HP-40	Tuerca, M6	Nut, M6
41	BON-P-GE-16.0HP-41	Culata Junta	Gasket, Cylinder Head
42	BON-P-GE-16.0HP-42	Pin, φ12 × 20	Pin,φ12×20
43	BON-P-GE-16.0HP-43	Varilla de empuje	Push Rod
44	BON-P-GE-16.0HP-44	Alzaválvulas	Tappet
45	BON-P-GE-16.0HP-45	Válvula de escape	Exhaust Valve
46	BON-P-GE-16.0HP-46	Válvula de admisión	Intake Vavle
47	BON-P-GE-16.0HP-47	Juego de anillos de pistón	Piston Ring Set

48	BON-P-GE-16.0HP-48	Anillo de seguridad	Circlip
49	BON-P-GE-16.0HP-49	Pasador del pistón	Piston Pin
50	BON-P-GE-16.0HP-50	Pistón	Piston
51	BON-P-GE-16.0HP-51	Ensamblaje de biela	Connecting Rod Assembly
52	BON-P-GE-16.0HP-52	Conjunto de soporte de engranaje del gobernador	Governor Gear Bracket Assembly
53	BON-P-GE-16.0HP-53	Perno, M6 × 12	Bolt, M6×12
54	BON-P-GE-16.0HP-54	Sensor de aceite	Oil Sensor
55	BON-P-GE-16.0HP-55	Cojinete, TM6207	Bearing, TM6207
56	BON-P-GE-16.0HP-56	Cigüeñal	Crankshaft
57	BON-P-GE-16.0HP-57	Llave Woodruff	Woodruff Key
58	BON-P-GE-16.0HP-58	Árbol de levas	Camshaft
59	BON-P-GE-16.0HP-59	Arandela, $\phi 16.2 \times 0.3 \times \phi 24$	Washer, $\phi 16.2 \times 0.3 \times \phi 24$
60	BON-P-GE-16.0HP-60	Pin, $\phi 8 \times 12$	Pin, $\phi 8 \times 12$
61	BON-P-GE-16.0HP-61	Junta, cárter	Gasket, Crankcase
62	BON-P-GE-16.0HP-62	Tapa del cárter	Crankcase Cover
63	BON-P-GE-16.0HP-63	Sello de aceite, $\phi 35 \times \phi 52 \times 7$	Oil Seal, $\phi 35 \times \phi 52 \times 7$
64	BON-P-GE-16.0HP-64	Perno, M8 × 38	Bolt, M8×38
65	BON-P-GE-16.0HP-65	Varilla graduada	Dipstick
66	BON-P-GE-16.0HP-66	Varilla graduada	Dipstick
67	BON-P-GE-16.0HP-67	Junta tórica, varilla medidora	O-Ring, Dipstick
68	BON-P-GE-16.0HP-68	Gobernador Gear	Governor Gear
69	BON-P-GE-16.0HP-69	Cojinete, 6202	Bearing, 6202
70	BON-P-GE-16.0HP-70	Eje de equilibrio	Balance Shaft
71	BON-P-GE-16.0HP-71	Arrancador eléctrico	Electric Starter
72	BON-P-GE-16.0HP-72	Caja del cigüeñal	Crankcase
73	BON-P-GE-16.0HP-73	Eje del engranaje del gobernador	Governor Gear Shaft
74	BON-P-GE-16.0HP-74	Arandela, $\phi 8 \times 0.8 \times \phi 20$	Washer, $\phi 8 \times 0.8 \times \phi 20$
75	BON-P-GE-16.0HP-75	Sello de aceite, $\phi 8 \times \phi 14 \times 4$	Oil Seal, $\phi 8 \times \phi 14 \times 4$
76	BON-P-GE-16.0HP-76	Pasador de chaveta	Cotter Pin
77	BON-P-GE-16.0HP-77	Palanca del gobernador	Governor Lever
78	BON-P-GE-16.0HP-78	Manguera de combustible	Fuel Hose

79	BON-P-GE-16.0HP-79	Abrazadera	Clamp
80	BON-P-GE-16.0HP-80	Primavera del gobernador	Governor Spring
81	BON-P-GE-16.0HP-81	Vínculo del acelerador	Throttle Linkage
82	BON-P-GE-16.0HP-82	Primavera inactiva	Idle Spring
83	BON-P-GE-16.0HP-83	Acortar	Clip
84	BON-P-GE-16.0HP-84	Perno, M6 × 10	Bolt, M6×10
85	BON-P-GE-16.0HP-85	Arandela, $\phi 12 \times 2 \times \phi 20$	Washer, $\phi 12 \times 2 \times \phi 20$
86	BON-P-GE-16.0HP-86	Perno de tierra	Earth Bolt
87	BON-P-GE-16.0HP-87	Perno, M8 × 35	Bolt, M8×35
88	BON-P-GE-16.0HP-88	Tablero de alambre	Wire Board
89	BON-P-GE-16.0HP-89	Perno, M6 × 8	Bolt, M6×8
90	BON-P-GE-16.0HP-90	Vivienda del ventilador	Blower Housing
91	BON-P-GE-16.0HP-91	Bobina de carga	Charging Coil
92	BON-P-GE-16.0HP-92	Perno, M6 × 28	Bolt, M6×28
93	BON-P-GE-16.0HP-93	Módulo de ignición	Ignition Module
94	BON-P-GE-16.0HP-94	Acortar	Clip
95	BON-P-GE-16.0HP-95	Sello de aceite, $\phi 35 \times \phi 52 \times 7$	Oil Seal, $\phi 35 \times \phi 52 \times 7$
96	BON-P-GE-16.0HP-96	Volante	Flywheel
97	BON-P-GE-16.0HP-97	Ventilador	Cooling Fan
98	BON-P-GE-16.0HP-98	Copa de inicio	Starter Cup
99	BON-P-GE-16.0HP-99	Tuerca, M16 × 1,5	Nut, M16×1.5
100	BON-P-GE-16.0HP-100	Arrancador de retroceso	Recoil Starter