


BOMBA DE AGUA A GASOLINA



MODELO: - BON-P-WP1.5-224HL




1:10

No.	BOHNOEFFER CODIGO	DESCRIPTION IN ENGLISH	DESCRIPCION EN ESPANOL
1	BONWP1.5-224HL-P01	Bomba de agua	Water Pump
2	BONWP1.5-224HL-P02	Escudo de filtro de agua	Water Filter Shield
3	BONWP1.5-224HL-P03	Filtro de agua	Water Filter
4	BONWP1.5-224HL-P04	Abrazadera	Clamp
5	BONWP1.5-224HL-P05	Articulación	Joint
6	BONWP1.5-224HL-P06	Unión de tuberías	Pipe Joint
7	BONWP1.5-224HL-P07	Empaquetadura	Gasket
8	BONWP1.5-224HL-P08	Perno, M10×1.25×30	Bolt, M10×1.25×30
9	BONWP1.5-224HL-P09	Perno, M8×20	Bolt, M8×20
10	BONWP1.5-224HL-P10	Junta de entrada	Inlet Joint
11	BONWP1.5-224HL-P11	Lavadora	Washer
12	BONWP1.5-224HL-P12	Enchufar	Plug

13	BONWP1.5-224HL-P13	Lavadora	Washer
14	BONWP1.5-224HL-P14	Caja de la bomba	Pump Case
15	BONWP1.5-224HL-P15	Lavadora de caucho	Rubber Washer
16	BONWP1.5-224HL-P16	Cubrir	Cover
17	BONWP1.5-224HL-P17	Empaquetadura	Gasket
18	BONWP1.5-224HL-P18	Cubrir	Cover
19	BONWP1.5-224HL-P19	Unión de tuberías	Pipe Joint
20	BONWP1.5-224HL-P20	Articulación	Joint
21	BONWP1.5-224HL-P21	Abrazadera	Clamp
22	BONWP1.5-224HL-P22	Junta de salida	Outlet Joint
23	BONWP1.5-224HL-P23	Perno, M8×70	Bolt, M8×70
24	BONWP1.5-224HL-P24	Lavadora de caucho	Rubber Washer
25	BONWP1.5-224HL-P25	Cubierta del impulsor	Impeller Cover
26	BONWP1.5-224HL-P26	Impulso	Impeller
27	BONWP1.5-224HL-P27	Eje de conexión	Connecting Shaft
28	BONWP1.5-224HL-P28	Perno, M8×40	Bolt, M8×40
29	BONWP1.5-224HL-P29	Arandela, $\phi 8 \times 1.5 \times \phi 16$	Washer, $\phi 8 \times 1.5 \times \phi 16$
30	BONWP1.5-224HL-P30	Sello	Seal
31	BONWP1.5-224HL-P31	junta tórica	O-Ring
32	BONWP1.5-224HL-P32	Cubierta lateral	Side Cover
33	BONWP1.5-224HL-P33	Tuerca, M10×1.25	Nut, M10×1.25
34	BONWP1.5-224HL-P34	Motor	Engine
35	BONWP1.5-224HL-P35	Tuerca, M8	Nut, M8
36	BONWP1.5-224HL-P36	Perno, M8×48	Bolt, M8×48
37	BONWP1.5-224HL-P37	Marco	Frame
38	BONWP1.5-224HL-P38	Tuerca, M6	Nut, M6

39	BONWP1.5-224HL-P39	Almohadilla amortiguadora	Damping Pad
40	BONWP1.5-224HL-P40	Tornillo, M6×12	Screw, M6×12
41	BONWP1.5-224HL-P41	Filtrar	Filter
42	BONWP1.5-224HL-P42	Almohadilla amortiguadora	Damping Pad
43	BONWP1.5-224HL-P43	Perno, M6×16	Bolt, M6×16
44	BONWP1.5-224HL-P44	junta tórica	O-Ring
45	BONWP1.5-224HL-P45	Impulso	Impeller
46	BONWP1.5-224HL-P46	Voluta	Volute



1 : 10

No.	BOHNOEFFER CODIGO	DESCRIPTION IN ENGLISH	DESCRIPCION EN ESPANOL
1	BONWP1.5-224HL-E01	Perno, M6×16	Bolt, M6×16
2	BONWP1.5-224HL-E02	Tapa de la válvula	Valve Cover
3	BONWP1.5-224HL-E03	Manguera de respiradero	Breather Hose
4	BONWP1.5-224HL-E04	Junta, tapa de válvula	Gasket, Valve Cover
5	BONWP1.5-224HL-E05	Conjunto de balancín	Rocker Arm Assembly
6	BONWP1.5-224HL-E06	Base de balancín	Rocker Arm Base
7	BONWP1.5-224HL-E07	Perno, M6×10	Bolt, M6×10
8	BONWP1.5-224HL-E08	Sudario	Shroud
9	BONWP1.5-224HL-E09	Tapa de ajuste de válvula, escape	Valve Adjust Cap, Exhaust
10	BONWP1.5-224HL-E10	Asiento de resorte de válvula	Valve Spring Seat

11	BONWP1.5-224HL-E11	Asiento de resorte de válvula	Valve Spring Seat
12	BONWP1.5-224HL-E12	Resorte de válvula	Valve Spring
13	BONWP1.5-224HL-E13	Sello de válvula de admisión	Intake Valve Seal
14	BONWP1.5-224HL-E14	Perno, M8×65	Bolt, M8×65
15	BONWP1.5-224HL-E15	Cabeza de cilindro	Cylinder Head
16	BONWP1.5-224HL-E16	Tuerca, M8	Nut, M8
17	BONWP1.5-224HL-E17	Silenciador	Muffler
18	BONWP1.5-224HL-E18	junta, silenciador	Gasket, Muffler
19	BONWP1.5-224HL-E19	Espárrago, M8×34	Stud, M8×34
20	BONWP1.5-224HL-E20	Bujía	Spark Plug
21	BONWP1.5-224HL-E21	Espárrago, M6×110	Stud, M6×110
22	BONWP1.5-224HL-E22	Junta, Aislante De Carburador	Gasket, Carburetor Insulator
23	BONWP1.5-224HL-E23	Aislante	Insulator
24	BONWP1.5-224HL-E24	Junta, Carburador	Gasket, Carburetor
25	BONWP1.5-224HL-E25	Carburador	Carburetor
26	BONWP1.5-224HL-E26	Junta, Carburador	Gasket, Carburetor
27	BONWP1.5-224HL-E27	Conjunto de filtro de aire	Air Filter Assembly
28	BONWP1.5-224HL-E28	Cubierta del filtro de aire	Air Filter Cover
29	BONWP1.5-224HL-E29	Cubierta del filtro de aire	Air Filter Cover
30	BONWP1.5-224HL-E30	Tuerca de mariposa	Butterfly Nut
31	BONWP1.5-224HL-E31	Elemento de filtro de aire	Air Filter Element
32	BONWP1.5-224HL-E32	junta, filtro de aire	Gasket, Air Filter
33	BONWP1.5-224HL-E33	Cubierta inferior del filtro de aire	Air Filter Lower Cover
34	BONWP1.5-224HL-E34	Hoja de silenciador	Muffler Sheet
35	BONWP1.5-224HL-E35	Ensamblaje de la base del filtro de aire	Air Filter Base Assembly

36	BONWP1.5-224HL-E36	Tuerca, M6	Nut, M6
37	BONWP1.5-224HL-E37	Culata Junta	Gasket, Cylinder Head
38	BONWP1.5-224HL-E38	Clavija, $\phi 10 \times 16$	Pin, $\phi 10 \times 16$
39	BONWP1.5-224HL-E39	Varilla de empuje	Push Rod
40	BONWP1.5-224HL-E40	Alzaválvulas	Tappet
41	BONWP1.5-224HL-E41	Válvula de escape	Exhaust Valve
42	BONWP1.5-224HL-E42	válvula de admisión	Intake Valve
43	BONWP1.5-224HL-E43	Juego de anillos de pistón	Piston Ring Set
44	BONWP1.5-224HL-E44	anillo de seguridad	Circlip
45	BONWP1.5-224HL-E45	Pasador del pistón	Piston Pin
46	BONWP1.5-224HL-E46	Pistón	Piston
47	BONWP1.5-224HL-E47	Conjunto de biela	Connecting Rod Assembly
48	BONWP1.5-224HL-E48	Perno, M8 \times 32	Bolt, M8 \times 32
49	BONWP1.5-224HL-E49	Sello de aceite, $\phi 25 \times \phi 41.25 \times 6$	Oil Seal, $\phi 25 \times \phi 41.25 \times 6$
50	BONWP1.5-224HL-E50	Cubierta del cárter	Crankcase Cover
51	BONWP1.5-224HL-E51	Junta, Cárter	Gasket, Crankcase
52	BONWP1.5-224HL-E52	Clavija, $\phi 8 \times 14$	Pin, $\phi 8 \times 14$
53	BONWP1.5-224HL-E53	Cojinete, TM6205	Bearing, TM6205
54	BONWP1.5-224HL-E54	Árbol de levas	Camshaft
55	BONWP1.5-224HL-E55	Cigüeñal	Crankshaft
56	BONWP1.5-224HL-E56	Clave de aspérula	Woodruff Key
57	BONWP1.5-224HL-E57	sensor de aceite	Oil Sensor
58	BONWP1.5-224HL-E58	Junta tórica, $\phi 15,8 \times 2,5$	O-Ring, $\phi 15.8 \times 2.5$
59	BONWP1.5-224HL-E59	Varilla graduada	Dipstick
60	BONWP1.5-224HL-E60	Engranaje del gobernador	Governor Gear
61	BONWP1.5-224HL-E61	Perno, M6 \times 12	Bolt, M6 \times 12

62	BONWP1.5-224HL-E62	Montaje del soporte del engranaje del gobernador	Governor Gear Bracket Assembly
63	BONWP1.5-224HL-E63	Abrazadera	Clamp
64	BONWP1.5-224HL-E64	Manguera de combustible, $\phi 4 \times \phi 8 \times 155$	Fuel Hose, $\phi 4 \times \phi 8 \times 155$
65	BONWP1.5-224HL-E65	Chaqueta de manguera de combustible	Fuel Hose Jacket
66	BONWP1.5-224HL-E66	Tapa de combustible	Fuel Cap
67	BONWP1.5-224HL-E67	Depósito de combustible	Fuel Tank
68	BONWP1.5-224HL-E68	Perno, M6×28	Bolt, M6×28
69	BONWP1.5-224HL-E69	Tuerca, M6	Nut, M6
70	BONWP1.5-224HL-E70	Palanca del gobernador	Governor Lever
71	BONWP1.5-224HL-E71	pasador de chaveta	Cotter Pin
72	BONWP1.5-224HL-E72	Sello de aceite, $\phi 6 \times \phi 11 \times 4$	Oil Seal, $\phi 6 \times \phi 11 \times 4$
73	BONWP1.5-224HL-E73	Junta tórica, $\phi 5,2 \times 1,9$	O-Ring, $\phi 5.2 \times 1.9$
74	BONWP1.5-224HL-E74	Eje de engranaje del gobernador	Governor Gear Shaft
75	BONWP1.5-224HL-E75	primavera del gobernador	Governor Spring
76	BONWP1.5-224HL-E76	Enlace del acelerador	Throttle Linkage
77	BONWP1.5-224HL-E77	Primavera ociosa	Idle Spring
78	BONWP1.5-224HL-E78	Caja del cigüeñal	Crankcase
79	BONWP1.5-224HL-E79	sensor de aceite	Oil Sensor
80	BONWP1.5-224HL-E80	Perno de drenaje	Drain Bolt
81	BONWP1.5-224HL-E81	Arandela, $\phi 10 \times 1.5 \times \phi 16$	Washer, $\phi 10 \times 1.5 \times \phi 16$
82	BONWP1.5-224HL-E82	Módulo de ignición	Ignition Module
83	BONWP1.5-224HL-E83	Perno, M6×25	Bolt, M6×25
84	BONWP1.5-224HL-E84	Escudo inferior	Lower Shield
85	BONWP1.5-224HL-E85	Perno, M6×12	Bolt, M6×12

86	BONWP1.5-224HL-E86	Acortar	Clip
87	BONWP1.5-224HL-E87	Perno, M6×20	Bolt, M6×20
88	BONWP1.5-224HL-E88	Sello de aceite, φ25×φ41.25×6	Oil Seal, φ25×φ41.25×6
89	BONWP1.5-224HL-E89	Volante	Flywheel
90	BONWP1.5-224HL-E90	Ventilador	Cooling Fan
91	BONWP1.5-224HL-E91	Copa de inicio	Starter Cup
92	BONWP1.5-224HL-E92	Tuerca, M14×1.5	Nut, M14×1.5
93	BONWP1.5-224HL-E93	Arrancador de retroceso	Recoil Starter
94	BONWP1.5-224HL-E94	Carcasa del soplador	Blower Housing
95	BONWP1.5-224HL-E95	Arrancador de retroceso	Recoil Starter
96	BONWP1.5-224HL-E96	Arandela, φ6	Washer, φ6
97	BONWP1.5-224HL-E97	Perno, M6×10	Bolt, M6×10
98	BONWP1.5-224HL-E98	Perno, M6×14	Bolt, M6×14
99	BONWP1.5-224HL-E99	Interruptor de parada	Stop Switch
100	BONWP1.5-224HL-E100	Tapón de aceite	Oil Plug